


- IMPORTANT** Read all instructions before installing plate. Retain for future reference.
- SAFETY:** Turn the power at off main fuse/breaker panel before attempting any electrical work. This luminaire must be wired in accordance with local electrical codes and ordinances. Grounding connections should be done in the detachable junction box.
- WARNING:** Make sure the power is OFF from the electrical panel before starting or installation attempting any maintenance.

DRIVER	Model	CL-DL3-2007-38D-5CCT
	Input	110-120VAC 50/60Hz
	Output	33-38V DC 160mA
	Lifetime	50000 Hours
	Operating Temperature	-40°C to +40°C
	Dimming	Triac dimming (120V AC input only)
LIGHT	Approved Location	Suitable for damp locations.
	Energy used	7W
	Lumen	560lm
	CCT Options	2700K-3000K-3500K-4000K-5000K
	Beam Angle	38 Degree
	CRI	Ra>90
	Approved Location	Suitable for wet locations.

Dimmer Compatibility List			
for LED Recessed Lights. Dimmable down to 10%.			
BRAND	FAMILY	MODEL	CL-DL3-2007-40D-5CCT
LUTRON	SKYLARK CONTOUR	CTCL-153PDH	1-15
		CTCL-153P	1-15
		CT-600P	1-15
LEVITON	DECORA	DVCL-153P	1-15
		6672	1-15
PASS & SEYMOUR	HARMONY	HCL453PTCCCV6	1-15

Fixture Assembly



Installation

- Nail-in the mounting plate to the ceiling joist. Measure the position of the opening on the mounting plate from each wall. (Fig.1)
- Install the drywall on to the ceiling. (Fig.2)
- Cut-out a circle where the mounting plate opening is located. (Fig.3)
- Pull the supply wire through the cut-out hole. Do the electrical supply connection in the detachable junction box (Note: A licensed electrician must do the connections as per the local electrical code). Insert the junction box into the ceiling. (Fig.4)
- Do the connection to the luminaire and close the quick connect box. (Fig.5)
- New construction applications:** Hardwire box shall be firmly secured to studs, joists, or similar fixed structural units
- Remodel applications:** Do not require the hardwire box to be firmly secured after the mounting plates, studs, joists, or structural units that have been concealed. Snap off the hardwire box tabs then insert into ceiling FIG 4
- Push the spring clips upwards and push the luminaire into the cut hole of the ceiling. Release the spring clips and align the luminaire to sit properly over the ceiling cut hole. (Fig.6)
- Switch on the supply breaker and turn on the luminaire.

